



No.	Qty.	Description	Part No.
1	1	Belt Guard Assembly	UV-411-381-002
2	1	Pulley w/ Taper Lock Bushing	UV-266-169-025
3	1	Motor Pulley (3 groove)	UV-085-031-619
4		Belt Guard Assembly	UV-411-381-002
5	1	Belt Guard Bracket	UV-411-374-001
6	1	Sight Glass Level	UV-085-036-101
7	1	Oil Reservoir Cover	UV-419-109-012
8	1	Reservoir Cover Gasket	UV-264-127-001
9	3	Motor Bracket Pin	UV-275-233-002
10	2	Swivel Block	UV-286-122-006
11	1	Motor Platform	UV-299-089-008
12	1	Shaft	UV-252-616-012
13	2	Woodruff Key #G	UV-264-524-001
14	1	Key Eccentric	UV-408-324-005
15		Woodruff Key #G	UV-264-524-001
16	6	Spacer Stud	UV-298-799-001
17	2	End Cap	UV-262-315-005
18	2	"O" Ring	UV-085-019-755
19	2	Seal Assembly	UV-085-038-766
20	2	Lock Nut	UV-085-019-492
21	2	Lock Washer	UV-085-019-491
22	2	Ball Bearing	UV-085-019-757
23	1	Shaft Shoulder Ring	UV-262-318-003
24	2	Side Cover	UV-262-508-018
25	1	Motor Support Eyebolt	UV-263-250-007
26	1	Oil Reservoir	UV-404-521-013
27	1	Housing Gasket	UV-246-765-002
28	2	Brass Cock	UV-085-033-233
29	1	Oil Baffle	UV-264-504-003
30	2	Valve Cover Plate Gasket	UV-246-763-002
31	2	Valve Cap	UV-403-626-003
32	2	Valve Seat	UV-403-636-002
33	1	Pump Housing	UV-263-842-011
34	1	Gas Ballast Assembly	UV-085-021-965
35	1	Eccentric	UV-278-575-001
36	1	Piston & Slide	UV-243-595-011
37	2	Hinge Bar (2)	UV-297-857-004
38		Side Cover	UV-262-508-019
39		Spacer Stud	UV-298-799-001
40	1	Flywheel Guard Assembly	UV-410-736-002
41	1	Flywheel w/ Taper Lock Bushing	UV-266-169-027
42	1	Flywheel Guard Assembly	UV-266-169-027