



No.	Qty.	Description	Part Number
1	1	Belt Guard Assembly (Outer Piece)	UV-408-867-4
2	1+	Motor Pulley (4 Grooves)	UV-085-012-593
3	1*+	V Belt (Set of 4)	UV-085-013-726
4	1	Belt Guard Assembly (Inner Piece)	UV-408-867-4
5	1	Bracket	UV-408-306-6
6	1	Bracket	UV-408-306-5
7	1+	Pulley w/ Taper Lock Bushing	UV-268-783-5
8	1+	End Cap (Drive End)	UV-262-315-5
9	2*+	"O" Ring	UV-085-019-755
10	1*+	Mechanical Seal	UV-085-029-600
11	2+	Lock Nut	UV-085-019-492
12	2+	Lock Washer	UV-085-019-491
13	2+	Ball Bearing	UV-085-019-757
14	1+	Shaft Shoulder Ring	UV-262-318-3
15	1+	Side Plate (Drive End)	UV-262-508-28
16	1+	Woodruff Key	UV-264-524-1
17	2+	Key Eccentric	UV-408-324-5
18	1+	Shaft	UV-262-992-5
19	2+	Ball Valve	UV-085-021-811
20	2+	Check Valve	UV-085-021-965
21	2+	Piston & Slide	UV-243-595-11
22	4+	Hinge Bars	UV-297-857-4
23	1+	Solid Eccentric	UV-252-459-1
24	1+	Hinge Bar Spacer	UV-268-788-1
25	6+	Nylock S.H Cap Screw	UV-085-021-745
26	1+	Bearing Ring	UV--264-785-2
27	1+	Roller Bearing	UV-085-033-232
28	1+	Retaining Pin	UV-270-231-1
29		Gage Port	

* Recommended Spare Part (Wear Item)

+ Parts Normally Stocked



No.	Qty.	Description	Part Number
30	1+	Pump Housing	UV-262-712-25
31	4*+	Valve Base	UV-403-636-003
32	4+	Valve Cap	UV-403-626-003
33	1*+	Oil Distributor Gasket	UV-269-037-1
34	1+	Oil Distributor	UV-269-256-5
35	1*+	Housing Gasket	UV-269-043-1
36	1	Oil Reservoir	UV-299-66-24
37	2	Tubing	UV-269-286-13
38	1	Brass Pipe	UV-085-036-053
39	1+	Flow Indicator	UV-085-02-037
40	1*+	Solenoid Valve	UV-085-035-837
41	1	Oil Level Indicator	UV-085-036-101
42	1	Cover Plate	UV-419-109-5
43	1*+	Cover Plate Gasket	UV-248-411-6
44	2	Motor Bracket Pin	UV-085-035-996
45	2	Swivel Block	UV-287-950-3
46	1	Motor Platform	UV-288-202-5
47	1	Eye Bolt Base	UV-263-249-4
48	1	Brass Cock	UV-085-033-233
49	1+	Hollow Eccentric	UV-278-575-1
50	2+	Piston & Slide	UV-243-595-11
51	1+	Side Plate (Dead End)	UV-262-508-21
52	12+	Shaft Shoulder Ring	UV-262-318-3
53	2+	Ball Bearing	UV-085-019-757
54	2+	Lock Nut	UV-085-019-492
55	2+	Lock Washer	UV-085-019-491
56	2*+	"O" Ring	UV-085-019-755
57	1+	End Cap (Dead End)	UV-262-315-5
58	2+	Ball Valve	UV-085-021-811
59	2+	Check Valve	UV-085-021-965

* Recommended Spare Part (Wear Item)

+ Parts Normally Stocked



(Items Not Pictured)

No.	Qty	Part Number	Description
60	4+	UV-263-840-004	Valve Assembly
61	4*+	UV-243-926-002	Valve Plate Gasket
62	8*+	UV-274-172-001	Spring
63	8*+	UV-276-781-002	Valve Clapper
64	1*+	UV-085-029-430	Solenoid Valve Coil 220/440v 50/60 CY
65	1*+	UV-085-029-427	Solenoid Valve Coil 550v 60 CY
66	1*+	UV-085-029-431	Solenoid Valve Coil 110v 60 CY
67	2*+	UV-085-024-138	Spring
68	2*+	UV-085-024-135	Dynamic "O" Ring
69	2	UV-085-024-136	Static "O" Ring
70	2*+	UV-254-539-002	Stokes V Lube Pump Oil, Label F, 5 Gal. can
71	1*+	UV-285-186-002	Stokes V Lube Pump Oil, Label F, 2 Gal Can
72	1*+	UV-085-034-530	Glass Dome and Eno., Gasket
73	2+	UV-085-025-325	Expansion Plug, 2 1/2" Dia. x .083" Thk
74	8+	UV-085-021-873	Expansion Plug, 1 7/8" Dia. x .083" Thk.
75	1*+	UV-085-038-301	Sealing Compound

* Recommended Spare Part (Wear Item)

+ Parts Normally Stocked